



**Air
Controls
Products**

TPMS



Dill TPMS Relearn Procedure – A0301

A properly formatted TPMS scan tool is required for this procedure.

Sensor Relearn Procedure

1. If using a Bartec tool, use the “Relearn” option, not “Test Sensor”.
If using an Ateq tool, use the “Service TPMS” menu, not “Check”.
2. Starting with the LF tire, use the scan tool to scan each sensor in the following order: LF, RF, RR, LR, & full size spare (if equipped).
3. Turn ignition to the ON position.
4. Connect scan tool to OBDII port and upload sensor IDs.
5. With the ignition still in the ON position, re-scan each sensor.
6. Test drive the vehicle above 30mph or more for at least 10 minutes, monitor the low tire pressure monitor to ensure it does not blink.

For more information contact Dill or your nearest Dill distributor.