



FAST-N-FLATOR

REMOVE CORE. INFLATE. NO AIR LOSS.

The patented tool that removes the core & inflates the tire - all in one!



**SEE IT IN
ACTION!**

Scan to watch
how it works



PATENTED ALL-IN ONE TOOL

Remove valve core,
inflate the tire, &
re-install valve core



VISUAL VERIFICATION


Clear window
eliminates guesswork
from core removal
and installation



PROPER TORQUE

USA-Made torque knob
ensures valve core is
installed correctly for a
leak-free seal

STOP WASTING TIME & LOSING AIR



- Lose air when removing chuck
- Slower service times
- More steps = more room for error
- Valve core exposed to dirt & grime

SERVICE FASTER W/ FAST-N-FLATOR



- No air loss when chuck is removed
- All-in-one tool
- Faster, more efficient service
- Get it right the first time w/ preset torque

