



**Air
Controls
Products**

TPMS



Dill TPMS Relearn Procedure – I037

This vehicle's TPMS is Indirect which utilizes the ABS wheel speed sensors.

System Calibration Procedure

1. Set tire pressure to door placard specs.
2. Press MENU/CLOCK button or HOME if a touchscreen.
3. Select "Settings."
4. Select "Vehicle Settings" or "Vehicle."
5. Select "TPMS Calibration."
6. Select "Calibration."
7. The system will be calibrated after 30 minutes of driving between 30mph and 60mph.

TIP:

If problems persist, verify that all four tires are the same.

- Make and Model of the tire
- Size (should match tire size listed on the door placard)
- Country of Origin
- Load Range
- Ply Count

For more information contact Dill or your nearest Dill distributor.